










BRAKE CONTROL

SST

	09023-00101	Union Nut Wrench 10 mm	-
	09214-76011	Crankshaft Pulley Replacer	-
	09520-00031	Rear Axle Shaft Puller	-
	(09520-00040)	Shocker	-
	09521-00020	Drive Shaft Boot Clamping Tool	-
	09950-00020	Bearing Remover	-

RECOMMENDED TOOLS

	09031-00040	Pin Punch .	Skid control sensor
	09082-00040	TOYOTA Electrical Tester	-
	(09083-00150)	Test Lead Set	-

EQUIPMENT

Soft jaw vise	Skid control sensor
Torque wrench	-

LUBRICANT

Item	Capacity	Classification
Brake fluid	-	SAE J1703 or FMVSS No. 116 DOT3